

Easyboot Epic Sizing Chart

Size	Width in inches	Length in inches	Size	Width in mm	Length in mm
Pony	3 3/16" - 3 3/8"	3 3/8" - 3 5/8"	Pony	78-85mm	85-92mm
000	3 3/8" - 3 13/16"	3 5/8" - 4 3/16"	000	86-97mm	93-105mm
00	3 13/16" - 4 3/8"	4 3/16" - 4 5/8"	00	98-110mm	106-117mm
0	4 3/8" - 4 9/16"	4 5/8" - 4 15/16"	0	111-116mm	118-124mm
1	4 9/16" - 4 7/8"	4 15/16" - 5 1/8"	1	117-123mm	125-130mm
2	4 7/8" - 5 1/8"	5 1/8" - 5 9/16"	2	124-130mm	131-140mm
3	5 1/8" - 5 1/2"	5 9/16" - 5 15/16"	3	131-139mm	141-150mm
4	5 1/2" - 5 15/16"	5 15/16" - 6 7/16"	4	140-150mm	151-163mm
5	5 15/16" - 6 7/16"	6 7/16" - 6 7/8"	5	151-163mm	164-174mm
6	6 7/16" - 6 7/8"	6 7/8" - 7 7/16"	6	164-175mm	175-188mm
7	6 7/8" - 7 9/16"	7 7/16" - 7 3/4"	7	176-192mm	189-195mm

Easyboot Epic Sizing – If you have purchased Epics prior to 2012 then your size will remain the same if you purchase the new improved version released in May 2012.

How to get the correct size boot for your horse:

1. Measure the width of the hoof across the bottom at the widest point.
2. Measure the length of the hoof from the toe to the buttress line of the heel.

The buttress line is the farthest weight bearing point of the heel.

3. Compare your measurement with the proper size chart.
4. Ideally, the width and length measurement will fit into the same Easyboot Epic size. If the width and length measurements indicate different Easyboot Epic sizes, select the larger Easyboot Epic size. If the width and length measurements are different by more than one size, EasyCare hoof boots are not recommended.

EasyCare Down Under www.easycaredownunder.com.au

Email easycaresdownunder@bigpond.com Ph 02 4457-3022

